

SINGER® Embroidery Quick Reference Guide

PROJECT	STABILIZER	HOOPING	NEEDLE	BOBBIN THREAD	NEEDLE THREAD
T-shirts	Soft Mesh Cut-Away	Hoop fabric and stabilizer together	Singer Chromium #2001, Size 11	Bobbinfill	Rayon is most often used
Fleece	Cut-Away, Use Spray Adhesive - Dense design, use topper	Use spray adhesive to hold fleece to hooped stabilizer	Singer Chromium #2001, Size 14	Bobbinfill	Polyester or Rayon
Towels	Topper required. Tear-Away on back	Hoop back stabilizer first, then pin topper, towel, and backing together	Singer Chromium #2000, Size 14	Same color as needle thread or towel	Polyester is recommended
Sweater Knits	Cut-Away	Use spray adhesive to hold sweater to hooped stabilizer	Singer Chromium #2001, Size 14	Bobbinfill	Polyester or Rayon
Light Weight Fabrics	Water-Soluble, Light Tear-Away, or Organza Fabric	Hoop fabric & stabilizer together	Singer Chromium #2000, Size 11	Bobbinfill	Rayon is most often used
Heavy Weight Fabrics	Medium to Heavy Weight Tear-Away or Self-Adhesive Tear-Away	Use spray adhesive to hold fabric to hooped stabilizer	Singer Chromium #2000, Size 14	Bobbinfill	Polyester or Rayon
Denim	Medium to Heavy Weight Cut-Away or Self-Adhesive Cut-Away	Use spray adhesive to hold fabric to hooped stabilizer or Hoop self-adhesive and secure fabric on top	Singer Chromium #2000, Size 14	Bobbinfill	Polyester or Rayon
Napped Fabrics	Medium to Heavy Weight Tear-Away or Self-Adhesive Tear-Away	Hoop stabilizer and secure fabric on top	Singer Chromium #2000, Size 14	Bobbinfill	Polyester or Rayon
Vinyl & Leather	Cut-Away or Self-Adhesive Cut-Away	Hoop stabilizer and secure fabric on top	Singer Chromium #2000, Smallest size acceptable for fabric	Bobbinfill	Polyester or Rayon

SINGER *is sewing made easy.*™